

```
Router#
Router#
*Jul 14 14:40:00.119: %LINK-3-UPDOWN: Interface Ethernet0/2, changed state to do
wn
*Jul 14 14:40:00.127: %LINK-3-UPDOWN: Interface Ethernet0/3, changed state to do
wn
*Jul 14 14:40:01.119: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/
2, changed state to down
*Jul 14 14:40:01.127: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/
3, changed state to down
Router#
Router#
Router#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#hostname R1
R1(config)#int e0/0
R1(config-if)#ip add 50.0.0.1 255.0.0.0
R1(config-if)#no shut
R1(config-if)#exit
R1(config)#
R1(config)#int e0/1
R1(config-if)#ip add 60.0.0.1 255.0.0.0
R1(config-if)#no shut
R1(config-if)#exit
R1(config)#
R1(config)#ex
% Ambiguous command: "ex"
R1(config)#end
R1#
*Jul 14 14:42:26.859: %SYS-5-CONFIG_I: Configured from console by console
R1#show ip int brief
Interface                IP-Address      OK? Method Status      Protocol
Ethernet0/0              50.0.0.1        YES manual up          up
Ethernet0/1              60.0.0.1        YES manual up          up
Ethernet0/2              unassigned      YES TFTP  down        down
Ethernet0/3              unassigned      YES TFTP  down        down
R1#
```

C:\WINDOWS\system32\cmd.exe

Pinging 50.0.0.1 with 32 bytes of data:

Destination host unreachable.
Destination host unreachable.
Destination host unreachable.
Destination host unreachable.

Ping statistics for 50.0.0.1:

Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\user>

C:\Documents and Settings\user>ping 50.0.0.2

Pinging 50.0.0.2 with 32 bytes of data:

Destination host unreachable.
Destination host unreachable.
Destination host unreachable.
Destination host unreachable.

Ping statistics for 50.0.0.2:

Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\user>ping 50.0.0.2

```
C:\WINDOWS\system32\cmd.exe
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>route print
=====
Interface List
0x1 ..... MS TCP Loopback interface
0x2 ...50 fe 9c 09 4f 00 ..... Intel(R) PRO/1000 MT Network Connection - Packet
Scheduler Miniport
=====
Active Routes:
Network Destination        Netmask          Gateway          Interface        Metric
50.0.0.0                    255.0.0.0        50.0.0.2         50.0.0.2         10
50.0.0.2                    255.255.255.255  127.0.0.1        127.0.0.1        10
50.255.255.255             255.255.255.255  50.0.0.2         50.0.0.2         10
127.0.0.0                  255.0.0.0        127.0.0.1        127.0.0.1        1
224.0.0.0                  240.0.0.0        50.0.0.2         50.0.0.2         10
255.255.255.255           255.255.255.255  50.0.0.2         50.0.0.2         1
=====
Persistent Routes:
None

C:\Documents and Settings\user>route add 60.0.0.0 mask 255.0.0.0 50.0.0.1
C:\Documents and Settings\user>
```

```
C:\WINDOWS\system32\cmd.exe

C:\Documents and Settings\user>route add 60.0.0.0 mask 255.0.0.0 50.0.0.1

C:\Documents and Settings\user>route print

=====
Interface List
0x1 ..... MS TCP Loopback interface
0x2 ...50 fe 9c 09 4f 00 ..... Intel(R) PRO/1000 MT Network Connection - Packet Scheduler Miniport
=====

Active Routes:
Network Destination        Netmask          Gateway          Interface        Metric
50.0.0.0                   255.0.0.0        50.0.0.2        50.0.0.2         10
50.0.0.2                   255.255.255.255  127.0.0.1       127.0.0.1         10
50.255.255.255            255.255.255.255  50.0.0.2        50.0.0.2         10
60.0.0.0                   255.0.0.0        50.0.0.1        50.0.0.2          1
127.0.0.0                  255.0.0.0       127.0.0.1       127.0.0.1          1
224.0.0.0                  240.0.0.0        50.0.0.2        50.0.0.2         10
255.255.255.255           255.255.255.255  50.0.0.2        50.0.0.2          1
=====

Persistent Routes:
None

C:\Documents and Settings\user>
```

```
C:\WINDOWS\system32\cmd.exe

Network Destination    Netmask          Gateway          Interface        Metric
    50.0.0.0           255.0.0.0        50.0.0.2         50.0.0.2         10
    50.0.0.2           255.255.255.255  127.0.0.1        127.0.0.1         10
  50.255.255.255       255.255.255.255  50.0.0.2         50.0.0.2         10
    60.0.0.0           255.0.0.0        50.0.0.1         50.0.0.2          1
    127.0.0.0          255.0.0.0        127.0.0.1        127.0.0.1          1
    224.0.0.0          240.0.0.0        50.0.0.2         50.0.0.2         10
  255.255.255.255     255.255.255.255  50.0.0.2         50.0.0.2          1
=====
Persistent Routes:
  None

C:\Documents and Settings\user>ping 60.0.0.2

Pinging 60.0.0.2 with 32 bytes of data:

Request timed out.
Request timed out.
Request timed out.
Request timed out.

Ping statistics for 60.0.0.2:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\user>
```

C:\WINDOWS\system32\cmd.exe

Windows IP Configuration

Ethernet adapter Local Area Connection:

```
Connection-specific DNS Suffix . :  
IP Address. . . . . : 60.0.0.2  
Subnet Mask . . . . . : 255.0.0.0  
Default Gateway . . . . . : 60.0.0.1
```

C:\Documents and Settings\user>ping 50.0.0.2

Pinging 50.0.0.2 with 32 bytes of data:

```
Reply from 50.0.0.2: bytes=32 time=2ms TTL=127  
Reply from 50.0.0.2: bytes=32 time=1ms TTL=127  
Reply from 50.0.0.2: bytes=32 time=1ms TTL=127  
Reply from 50.0.0.2: bytes=32 time=1ms TTL=127
```

Ping statistics for 50.0.0.2:

```
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),  
Approximate round trip times in milli-seconds:  
Minimum = 1ms, Maximum = 2ms, Average = 1ms
```

C:\Documents and Settings\user>